



Southeast Aerospace, Inc
 1399 General Aviation Dr
 Melbourne, Florida 32935 USA
sales@seaerospace.com
 Tel: 321-255-9877
 Fax: 321-255-9608
www.seaerospace.com

Bell 412 Capabilities List

Part Number	Model	Description	Capability
064-1009-00	KTR-905	VHF Comm	SEA Repair, Spares, Exchange
064-1023-00	KTR-908	VHF Comm	SEA Repair, Spares, Exchange
066-1041-00	KXP-755	Transponder	SEA Repair, Spares, Exchange
066-1044-00	KMR-675	Marker Receiver	SEA Repair, Spares, Exchange
066-1047-01	KDF-805	ADF Receiver	SEA Repair, Spares, Exchange
066-1066-02	KDM-706	DME	SEA Repair, Spares, Exchange
066-1069-01	KDI-572	DME Indicator	SEA Repair, Spares, Exchange
066-1071-00	KXP-756	Transponder	SEA Repair, Spares, Exchange
066-1077-00	KDF-806	ADF Receiver	SEA Repair, Spares, Exchange
066-1077-01	KDF-806	ADF Receiver	SEA Repair, Spares, Exchange
066-1078-00	KNR-634	Nav Receiver	SEA Repair, Spares, Exchange
066-4007-00	KNR-630	Nav Receiver	SEA Repair, Spares, Exchange
071-1076-00	KDA-697	RMI Adapter	SEA Repair, Spares, Exchange
071-1210-09	KFS-586	ADF Control	SEA Repair, Spares, Exchange
071-1215-40	KFS-598	Comm Control	SEA Repair, Spares, Exchange
071-1216-27	KFS-564	Nav Control	SEA Repair, Spares, Exchange
10035-11326		Altimeter	SEA Exchange
10035-11424		Altimeter	SEA Exchange
212-070-238-007		Altimeter	SEA Exchange
222-375-033-103		Standby Attitude Indicator	SEA Exchange
2593379-1	CS-412	Dual Remote Compensator	SEA Repair, Spares, Exchange
2593379-001	CS-412	Dual Remote Compensator	SEA Repair, Spares, Exchange
2593996-333	TARSYN 333	3-Axis Reference Gyro	SEA Spares, Exchange
2594484	FX-220	Flux Valve	SEA Repair, Spares, Exchange
4014267-902	RA-235	Radio Altimter Indicator	SEA Repair, Spares, Exchange
4020936-903	TARSYN H	3-Axis Reference Gyro	SEA Spares, Exchange
4030182-901	AC-702	Altitude Sensor	SEA Spares, Exchange
4300-8765-1L		Standby Attitude Indicator	SEA Spares, Exchange