



**Southeast Aerospace, Inc**  
 1399 General Aviation Dr  
 Melbourne, Florida 32935 USA  
[sales@seaerospace.com](mailto:sales@seaerospace.com)  
 Tel: 321-255-9877  
 Fax: 321-255-9608  
[www.seaerospace.com](http://www.seaerospace.com)

## Saab 340 Capabilities List

Part Number	Model	Description	Capability
064-1023-00	KTR-908	VHF Comm	SEA Repair
064-1023-02	KTR-908	VHF Comm	SEA Repair
066-03034-0022	KI-204	VOR/LOC/GS Indicator	SEA Repair
066-3034-22	KI-204	VOR/LOC/GS Indicator	SEA Repair
071-1210-04	KFS-586	ADF Control	SEA Repair
071-1215-24	KFS-598	Comm Control	SEA Repair
071-1234-00	KA-44B	ADF Antenna	SEA Repair
071-1276-08	KFS-576A	Transponder Control	SEA Repair
071-1284-04	KFS-586A	ADF Control	SEA Repair
10223N01R00		Prop Speed Indicator	
10224N01R00		Gas Generator Speed Indicator	
10225N01W00		Torque Indicator	
10226N01W00		Torque Indicator	
10227N01T00		I.T.T. Indicator	
10251N01T00		I.T.T. Indicator	
10252N01W00		Torque Indicator	
10253N01W00		Torque Indicator	
103680-4		OUTFLOW VALVE	
103682-1		OUTFLOW VALVE	
10388N01C00		Cabin Pressure Indicator	
10388N02C00		Cabin Pressure Indicator	
130538-1		CTL	
2117966-2		CONTROLLER	
501-1228-04	PS-835D	Emergency Power Supply	SEA Repair
501-1318-XX	SC-841A	Converter	SEA Repair
501-1712-02	PS-855B	Emergency Power Supply	SEA Repair
5934PA1		Altimeter	SEA Repair
60-1321-1		Light Power Supply	SEA Exchange
60-3757-3		Strobe Power Supply	SEA Exchange
622-0876-001	VIR-30A	Nav Receiver	SEA Repair
622-0876-201	VIR-30A	Nav Receiver	SEA Repair
622-1270-001	TDR-90	Transponder	SEA Repair
622-1879-001	VHF-20A	VHF Comm	SEA Repair
622-2362-001	ADF-60A	ADF Receiver	SEA Repair
622-2504-001	ANT-318	Radar Antenna	SEA Repair
622-2855-001	ALT-55B	Rad Alt Transceiver	SEA Repair
622-2855-011	ALT-55B	Rad Alt Transceiver	SEA Repair
622-3710-001	ANT-60B	Dual ADF Antenna	SEA Repair
622-3975-004	ALI-80A	Encoding Altimeter	SEA Exchange
622-3975-014	ALI-80A	Encoding Altimeter	SEA Exchange

Part Number	Model	Description	Capability
622-4096-001	346D-2B	PA Amplifier	SEA Exchange
622-5027-002	SVO-85B	Primary Servo	SEA Exchange
622-5812-001	FDU-70	Flux Detector Unit	SEA Repair
622-6093-012	WXP-85B	Radar Control Panel	SEA Exchange
622-6137-001	VIR-32	Nav Receiver	SEA Repair
622-6137-201	VIR-32	Nav Receiver	SEA Repair
622-6152-001	VHF-22A	VHF Comm	SEA Repair
622-6152-011	VHF-22A	VHF Comm	SEA Repair
622-6153-001	VHF-22B	VHF Comm	SEA Repair
622-6263-001	DME-42	DME	SEA Repair
622-6263-003	DME-42	DME	SEA Repair
622-6389-001	VHF-21A	VHF Comm	SEA Repair
622-6520-009	CTL-22	Comm Control	SEA Repair
622-6521-025	CTL-32	NAV CONTROL HEAD	SEA Repair
622-6522-017	CTL-62	ADF Control	SEA Repair
622-6523-001	CTL-92	Transponder Control	SEA Repair
622-6523-009	CTL-92	Transponder Control	SEA Repair
622-6523-013	CTL-92	Transponder Control	SEA Repair
622-6523-209	CTL-92	Transponder Control	SEA Repair
622-6523-213	CTL-92	Transponder Control	SEA Repair
622-6590-001	CAD-62	Control Adapter	SEA Repair
622-6590-002	CAD-62	Control Adapter	SEA Repair
622-7318-001	IND-42C	DME Indicator	SEA Repair
622-7337-001	WXT-250B	Radar Transceiver	SEA Repair
622-8154-001	FDU-70A	Flux Detector	SEA Repair
622-8332-001	CAD-31	Control Adapter	SEA Repair
622-8332-002	CAD-31	Control Adapter	SEA Repair
64050-660-X		AIRSPEED IND STBY	
64050-661-1		Airspeed Indicator, Standby	
64050-662-1		Airspeed Indicator, Standby	
64050-663-1		Airspeed Indicator, Standby	
64060-890-X		AIRSPEED IND	
64089-360-1		VERT SPEED IND	
64111-900-X		ALTIMETER	
641-370-X		ALTIMETER STBY	
64141-360-X		Altimeter	
64141-361-1		Altimeter	
64141-362-1		Altimeter	
64141-370-1		STBY ALTIMETER	
64141-372-1		Altimeter	
7239024-XXX		DC Electric Panel	
7239060-XXX		CTOT Panel	
72ESF2013-X		Total Fuel Used Indicator	
72FCF2050-3		Trim Tab Actuator	
742FCF2040		Trim Tab Actuator	
754661-8		Cabin Temp Controller	

Part Number	Model	Description	Capability
822-1193-001	FDU-3000	Flux Detector	SEA Repair
93-A055-40	A55B	CVR Microphone	SEA Repair
93-A055-60	A55B	CVR Microphone	SEA Repair
93-A100-83	A100A	CVR	SEA Repair
93-A151-20	A151B	CVR Control	SEA Repair
93-A152-30	A152B	CVR Control	SEA Repair
965-0476-088	MK II	GPWS	SEA Exchange
980-6001-XXX		C.V.R.	
980-6005-XXX		C.V.R.	
980-6019-XXX		C.V.R.	
DK100		CVR Beacon	SEA Repair
DK120		CVR Beacon	SEA Repair
G9950-1		Navigation Light	SEA Exchange
H341AMM1		Horizon Gyro	SEA Exchange
PC-251-123C		Static Inverter	SEA Exchange